

15 SIMOVIS

The software tool SIMOVIS V5.x is available for starting up, parameterizing and diagnosing the SIMOREG CM using a PC.

15.1 Scope of supply

SIMOVIS can be ordered under the **order no. 6RX1700-0BD64**.

The SIMOVIS tool can also be ordered as an **option** with **short code D64** together with a SIMOREG CM.

15.2 Installation of software

The software is supplied on CD together with the operating instructions in Word 97 format.

A brief overview of the CD contents can be found in file START.HTM. If you have installed an HTML Browser on your PC, you can start the overview by double clicking on START-HTML. Otherwise you can find information in text format in the README.TXT file.

After selection of the desired language, the SIMOVIS installation is called via the links [SIMOVIS V5.x - Install SIMOVIS](#) - [Start Installation](#).

For safety reasons, older Internet browsers are not in a position to start programs. In this case a "Setup.exe - Save as" dialog is displayed after [Start Installation](#).

In this case, you can start the Setup program manually in subcatalog:


SIMOVIS\setup.exe

Then following the instructions displayed by the installation program.

SIMOVIS is installed as standard in subcatalog C:\SIEMENS\SIMOVIS . An icon "SIMOVIS(USS)" for starting the program is displayed on the desktop.

15.3 Connection of SIMOREG CM to PC

The simplest link is made by connecting connector X300 on the front of the SIMOREG CM with a COM port of the PC using a cable that can be ordered under order no. 6SX7005-0AB00.



15.4 Further information

For further information regarding installation and operation of the SIMOVIS tool, including operation in a STEP7 environment and communication with equipment via Profibus as well as software operating instructions, can be found in the README.TXT file in the SIMOVIS installation directory and the ONLINE Help.

NOTE
SIMOVIS V5.x can run only under Windows95 or Windows NT 4.0, but not under Windows 3.x.